

Index

- .wav files, 91
- 1-AIF WAVE, 91
- 1-SEQUENCE, 89, 91
- 1-SOUND, 89, 91
- 1-WAV WAVE, 91
- 8-VoiceChorus. *See* User's Guide
- A**
- AC power, 2
- Access disks utils?, 98
- Accessories
 - in box, 1
 - optional, 6
- Add, 61
- Adding memory, 104
- AIF, 49, 89
- AKAI S-1000 sounds
 - loading, 91
 - translation, 91
- AKAISND, 91
- All Notes Off button, 6
- All Notes Off, enabling reception, 97
- All Sounds Off, enabling reception, 97
- ALL-BYPASS, 46
- Allocating memory, 6
- ALL-SEQS, 89, 91
- ALL-SESSION, 89, 91
 - automatic loading of, 89
- ALL-SND, 8
- ALL-SOUNDS, 89, 91
- als, 89
- Alt Bus, 34, 42
- Alter system pitch?, 95
- Amp Env Attack, 16
- Amp Env Decay, 16
- Amp Env Release, 16
- Amp&Filt Env Vel, 17
- Analog synth sounds. *See* Stomper
- Append sequence?, 75
- Architecture overview, 4–6
- Arrow, downward-pointing, 87
- ASR-10 and ASR-88 sounds
 - loading, 91
 - translation, 91
- ASR-SND, 91
- ASR-X Pro User's Guide, 1
- Assignable controllers, setting up, 97
- Attack Level (1), 31
- Attack Time (1), 31
- Audio Inputs
 - using, 50
- Audio Outputs, 1
- Auto-locating, 58
- Automatic loading of settings, 89
- Auto-punching, 65
- AutoSelect FXBus, 94
- Auto-Step, 63
- Auto-Zero Cross, 95
- Aux Out jacks, 1
- Auxiliary outs
 - overview, 42
 - routing sounds to
 - from pads, 27
 - from tracks, 13
- AuxOut1-4, 13, 27, 42
- B**
- Bank Select Recv, 18
- Bank&ProgChgRecv, 97
- Banks, defined, 8
- Bypassing effects, 46
- BYPD, 46
- C**
- Categories. *See* SoundFinder
- CD-ROM drive, using. *See* SCSI
- Chaining sequences. *See* Pattern mode
- Change sound type?, 102
- Chatter Box. *See* User's Guide
- Chorus→Rev. *See* User's Guide
- Clearing RAM, 101
- Click, 66
 - adding an effect, 66
 - and time signatures, 64
 - choosing its sound, 66
 - saving settings to FLASH, 102
 - sending it to the Aux Outs, 66
 - setting its beat, 66
 - setting its loudness, 66
 - setting its panning, 66
 - turning on and off, 66
- Click Timing, 66
- ClockSource, 97
- Comp→Dist→DDL. *See* User's Guide
- Connecting SCSI cables, 85
- Controllers list, 118
- Controlling an external sequencer, 97
- Copy [disk name] disk?. *See*
- Copy sound?, 38
- Copy this sequence?, 75
- Copy track?, 72
- Copying a SCSI disk. *See*
- Copying tracks
 - (Destination) Seq, 74
 - Destination Track, 74
 - DestTime, 74
 - overview, 72
 - Paste
 - Append, 73
 - Merge, 73
 - Replace, 73
 - Scope, 73
- Countoff
 - choosing its sound, 66
 - setting its length, 67
 - setting when it occurs, 66
- Countoff, 66
- Countoff Bars, 67
- Countoff Sound, 66
- Create a new song?, 77
- Create new sequence?, 60
- Creating a New Sequence, 60
- CTRL1, CTRL2, CTRL3 and CTRL4, 97
- CTRL3 and Patch Select buttons, 98
- CUSTOM category
 - quick selection, 9
- Cut ModSrc, 33
- Cutoff ModAmt, 33
- D**
- Data Entry Recv, 18
- DDL→Chorus. *See* User's Guide
- DDL→EQ. *See* User's Guide
- DDL→Flanger. *See* User's Guide
- DDL→Phaser. *See* User's Guide
- Decay Time (4), 31
- Defragmenting. *See* Optimizing a SCSI disk
- Delay Offset, 15
- Delta quantizing, 69–70
- Demo, playing, 4
- DEMO-SND, 102
- Destination Track, 74
- DesfTime, 74, 75
- Device ID. *See* SCSI device IDs
- Directories. *See* Folders
- Directory Sorted, 101
- Disk storage
 - copying SCSI disks, 98
 - de-fragmenting SCSI disks, 99
 - erasing disk files, 100
 - Floppy
 - overview, 81
 - formatting disks, 98
 - free space on disk, 101
 - loading files
 - computer files with long names, 92
 - procedure, 90
 - selecting a file, 92
 - selecting a memory location, 92
 - types of files, 90
 - overview of options, 81
 - renaming disk files, 100
 - resetting SCSI bus, 99
 - saving files
 - naming files, 90
 - procedure, 88
 - types of files, 89
- SCSI
 - bus
 - defined, 82
 - resetting, 99
 - connecting cables, 85
 - device IDs
 - explained, 83
 - setting the ASR-X Pro's, 95
 - folders
 - creating new, 88
 - default, 85
 - explained, 85
 - invisible, 85
 - navigating, 87
 - overview, 82–85
 - powering up, 85
 - preparing for, 85
 - scanning SCSI bus, 87
 - termination
 - explained, 84
 - setting the ASR-X Pro's, 95
 - troubleshooting, 86
 - selecting device, 86–87
 - write-protecting SCSI disks, 100
- Disk utilities
 - checking free space, 101
 - copying SCSI disks, 98
 - de-fragmenting SCSI disks, 99
 - erasing disk files, 100
 - formatting disks, 98
 - renaming disk files, 100
 - resetting SCSI bus, 99
 - write-protecting a SCSI disk, 100
- Dist→Auto Wah. *See* User's Guide
- Dist→Chorus. *See* User's Guide
- Dist→DDL→Trem. *See* User's Guide
- Dist→Flanger. *See* User's Guide
- Dist→Phaser. *See* User's Guide
- Dist→VCF→DDL. *See* User's Guide
- Distortion curves in effects, 47
- Down arrow symbol, 87
- DpthModSrc, 34
- Drum mapping, 23, 113
- Dry, 13
- Dry, defined, 41
- E**
- Edit Click/Countoff?, 65
- Edit global reverb?, 43
- Edit insert effect?, 43
- Edit MIDI settings?, 96
- Editing
 - any parameter, 3
 - any value, 3
- EDM sounds, loading, 91
- efa, 91
- efe, 91
- Effect bus. *See* FX Bus
- Effects
 - adding to pad sounds
 - changing busses, 27
 - adding to track sounds
 - changing busses
 - from front panel, 13
 - via MIDI, 13
 - bypassing, 46
 - distortion curves, 47
 - editing, 43
 - LFO waveshapes, 47
 - overview, 41–42
 - global reverb, defined, 42
 - insert control track, 41
 - insert effects

- defined, 41
 - list, 41
- real-time modulation, 44
 - modulators list, 44
- selecting, 43
- setting the insert control track, 46
- Effects Edit button, 43, 46
- Effects Select button, 43
- Electro Static Discharge, 103
- ENSONIQ Drum Map, 113
- ENSONIQ Percussion Map, 113
- ENSONIQDISK, 87
- Enter button, 3
- Enter MemoryManager?, 101
- Enter pattern mode?, 76
- Env1PitchModAmt, 31
- Env2CutoffModAmt, 33
- Envelope Mode, 31
- EPS and EPS 16 PLUS sounds
 - loading, 91
 - translation, 91
- EQ→Chorus→DDL. *See* User's Guide
- EQ→Comp→Gate. *See* User's Guide
- EQ→Reverb. *See* User's Guide
- Erase all sequences?, 76
- Erase disk files?, 100
- Erase memory banks?, 101
- Erase sound?, 101
- Erase this sequence?, 76
- Erase track?, 74
- Erase trk to end?, 74
- Erasing ASR-X Pro RAM, 101
- Erasing tracks
 - a MIDI controller, 74
 - a note range, 74
 - all recorded data, 74
 - assorted data, 74
 - only within a region, 74
- ESD, 103
- ESP2, 41
- ESSENTIALS, 89
- Essentials buttons
 - assigning favorite sounds to, 9
 - default sound assignments, 9
 - in sound selection, 9
 - saving sound assignments to disk, 89
 - to FLASH, 102
- Exit button, 3
- EXP Expansion Boards, 6
- Exp Name, 102
- Expansion options, 103
- Expressn(11) Recv, 18
- EXP-SND, 8
- F**
- Fast-forwarding in a sequence, 58
- fav, 89
- FDX-100, 1
- Filt Env Attack, 16
- Filt Env Decay, 16
- Filt Env Release, 17
- Filter Cutoff, 16, 33
- Filter Resonance, 16
- Final Mix mode, 63
- FinderPref, 35
- Fine Tuning (global), 96
- Fine Tuning (sound), 30
- Fine Tuning (track), 14
- Flanger →Rev. *See* User's Guide
- FLASH
 - saving settings to, 102
- FLASH, defined, 6
- Floppy disk
 - selecting for use, 86
- Floppy disks
 - advantages/disadvantages, 81
 - formatting, 98
 - inserting in drive, 82
 - removing from drive, 82
 - write-protection, 81
- Folders
 - creating new
 - using ASR-X Pro, 88
 - using computer, 88
 - explained, 85
 - invisible folders, 85
 - navigation, 87
 - where disk files are saved, 89
- Foot switch
 - assigning functions, 93
 - connecting, 2
- FootPedal(4) Recv, 18
- Formant Morph. *See* User's Guide
- Format disk?. *See* Free, 101
- Free, 101
- Free space
 - in RAM, 101
 - on disk, 101
- From= parameter, 65
- FtSw L and FtSw R, 93
- FX Bus
 - defined, 42
 - pad parameter, 27
 - track parameter, 13
- FX Bus (click), 66
- G**
- Gate Percentage, 63
- Gate Time, 62
- Gated Reverb. *See* User's Guide
- Glide Mode, 15, 30
 - changing via MIDI, 15
- Glide Time, 15, 30
- Global pitch bend, 95
- Global pitch table, 96
- Global reverb
 - defined, 42
 - editing, 43
 - Light, Medium, Wet, 42
 - list, 42
 - selecting, 43
- Global Reverb=, 43
- GM Kit Map, 114
- Group solo, 19
- Guitar Amp. *See* User's Guide
- H**
- Hall Reverb. *See* User's Guide
- Hard disk. *See* SCSI
- Held pitch bend, 96
- Hex wrench, 103
- I**
- In Bus, 51
- Index ModAmt, 29
- IndxModSrc, 29
- Input Level knob, 50
- Insert, 13
- Insert control track
 - defined, 41
 - setting, 46
- Insert effect parameters. *See* User's Guide
- Insert Effect=, 43
- Insert effects
 - adding to pad sounds, 27
 - adding to track sounds, 13
 - defined, 41
 - editing, 43
 - in song mode, 77
 - list, 41
 - real-time modulation, 44
 - modulators list, 44
 - selecting, 43
- Insert FX Bus
 - GlobalReverb Amt, 44
 - Input Mix, 44
- Insert: Mod Dest, 45
- Insert: Mod Dest Min and Max, 45
- Insert: Mod Src, 45
- Insert: Mod Src Min and Max, 45
- Installing
 - additional sample memory, 104–6
 - an EXP wave expansion board, 106–8
- Installing expansion options, 103
- Invert sample data?, 37
- Invisible folders. *See* Folders
- K**
- Key Group Assign, 35
- Key Range Hi, 17
- Key Range Lo, 17
- Keybd TimeScaling, 32
- Keybd Track, 33
- KeybdTrack, 30
- Kit Mapper, 23
- Knobs
 - Parameter and Value, 3
 - Sound Type and Sound Name, 3
- L**
- Large Plate. *See* User's Guide
- Large Room. *See* User's Guide
- Layers, in sounds, 22
- LEDs
 - flashing
 - Exit/No and Enter/Yes, 3
 - Mute/Solo, 19
 - Play and Record buttons, 59
 - Sampling Level, 50
- LFO Delay Time, 16, 34
- LFO Depth, 16, 34
- LFO Key Restart, 35
- LFO Pitch ModAmt, 30
- LFO Rate, 34
- LFO Rate ModAmt, 34
- LFO Shape, 34
- LFO Start Phase, 34
- LFO Sync, 35
- LFODepth ModAmt, 34
- LFOs in effects, 47
- LightReverb, 13
- LightReverb FX Bus, 44
- Lights. *See* LEDs
- Link, 32
- Load button, 90
- Load from disk?, 90
- Loading .wav files, 91
- Local Off Channel, 96
- Locating within a sequence, 58
- Location in sequence, 59
- Loop End, 29
- Loop Playback, 64
- Loop Start, 29
- Looping waves, 29, 95
- Low Key/High Key, 71
- M**
- Main Out jacks, 1
- Make a RAM kit from...?, 24
- Making a new sequence, 60
- Maximum number of notes, 6
- MediumReverb, 13
- MediumReverb FX Bus, 44
- Memory. *See* Sample memory
- Memory Manager, 101
 - Change sound type?, 102
 - Erase memory banks?, 101
 - Erase sound?, 101
 - EXP Name, 102
 - Show free memory?, 101
- Method, 69
- Metronome. *See* Click
- mfb, 89
- Mic/Line switch, 50
- mid, 89
- Middle C, 17
- MIDI
 - All Notes Off, 97
 - All Sounds Off, 97
 - ASR-X Pro note range, 21
 - Bank Selects
 - numbers, 8, 10
 - changing FX bus, 13
 - changing Glide Mode, 15
 - channels, described, 116
 - controllers
 - list, 118
 - reception behavior, 120

- editing track parameters, 12
 - enabling track reception
 - of Bank Selects, 18
 - of CTRL1-4 messages, 18
 - of Data Entry messages, 18
 - of Expression messages, 18
 - of Foot Pedal messages, 18
 - of Mod Wheel messages, 18
 - of Pan messages, 18
 - of Pitch Bend messages, 18
 - of Program Changes, 18
 - of Sustain/Sostenuto messages, 18
 - of Volume messages, 18
 - enabling transmission of data, 13
 - hardware, 116
 - implementation, 119
 - implementation chart, 119
 - jacks, 2
 - Local-off operation, 96
 - muting tracks, 19
 - note names/numbers, 21
 - playing sounds from, 10
 - Program Changes
 - numbers, 8, 10
 - recording to external sequencer, 96
 - Reset All Controllers, 97, 120
 - selecting sounds, 10
 - Song Position Pointer
 - receiving and transmitting, 97
 - synchronizing to external sequencer, 97
 - Tuning Standard
 - further info, 124
 - using, 124
 - using RPNs and NRPNs, 122
 - MIDI-OUT sounds
 - programming and using, 10
 - Mix (Expression), 12
 - Mixdown, 63
 - Mod Wheel(1) Recv, 18
 - Mode, 32
 - Modulators
 - sound modulators list, 27
 - Mono, using the ASR-X Pro in, 1
 - Move Note Offs, 72
 - Multiple ASR-X Pros, using, 97
 - Multi-Tap DDL. *See* User's Guide
 - Multi-timbral, defined, 116
 - mute, 19
 - Mute/Solo button, 19
 - Muting a track
 - using Mute/Solo button, 19
 - via MIDI, 19
- N**
- No button, 3
 - Noise Sync, 35
 - NoiseSourceRate, 35
 - NonLinReverb1. *See* User's Guide
 - NonLinReverb2. *See* User's Guide
 - Non-Registered Parameters. *See* NRPNs
 - Normal LFO Rates, 15
 - Normalize gain?, 36
 - Normalizing, defined, 51
 - NRPNs
 - defined, 122
 - list, 123
 - using, 123
- O**
- Octave Shift, 14
 - Octave Transpose buttons
 - using, 23
 - what they do, 23
 - when sending to pads, 54
 - Offset, defined, 11
 - On switch, 2
 - Opening the ASR-X Pro, 103
 - Operating system
 - defined, 108
 - upgrading, 108-9
 - What version am I using?, 108
 - What's the most recent version?, 108
 - Optimize [disk name] disk?, 99
 - Optimizing a SCSI disk, 99
 - OS. *See* Operating system
 - Outputs, 1
 - Override, defined, 11
- P**
- Pad Edit button, 25
 - Pad Pan, 26
 - Pad Process button, 36
 - Pad Sound button, 25
 - Pad Volume, 26
 - Pad Xpose, 23
 - Pads
 - editing, 24
 - PAD parameters, 26
 - editing pad sounds, 27
 - AMP parameters, 33
 - ENV1 parameters, 31
 - ENV2 parameters, 33
 - ENV3 parameters, 34
 - FILT parameters, 32
 - FLT1 & FLT2 parameters, 33
 - MISC parameters, 35
 - MOD parameters, 34
 - modulators, 27
 - PITCH parameters, 30
 - WAVE parameters, 29
 - processing waves
 - copying waves, 38
 - inverting data, 37
 - normalizing, 36
 - overview, 36
 - reducing sample bits, 37
 - time-scaling waves, 38
 - truncating, 38
 - volume scaling, 36
 - selecting sounds, 25
 - what pads play, 21
 - a whole kit at once, 23
 - resetting, 23
 - Pads Play Local, 96
 - Pan (click), 66
 - Pan ModAmt, 33
 - Pan ModSrc, 33
 - Pan(10) Recv, 18
 - Parameter knob, 3
 - Parameter, defined, 3
 - Parameters
 - editing track parameters, 11
 - Parametric EQ. *See* User's Guide
 - Paste, 73
 - Patch Select buttons
 - and CTRL3, 98
 - and MIDI, 24
 - as modulation devices, 98
 - modes
 - Live or Held, 93
 - what they do, 23
 - Patch Selects, 93
 - Pattern mode. *See* Pattern mode
 - Patterns. *See* Pattern mode
 - Pedals. *See* Foot switch
 - Percussion mapping, 113
 - Phaser →Rev. *See* User's Guide
 - Phones jack, 1
 - Pitch Bend Down, 30
 - Pitch Bend Recv, 18
 - Pitch Bend Up, 30
 - Pitch Bend Up, Pitch Bend Down (global), 95
 - Pitch Bend Up, Pitch Bend Down (track), 14
 - Pitch bend wheel, described, 95
 - Pitch Detuner. *See* User's Guide
 - Pitch ModAmt, 30
 - Pitch ModRange, 30
 - Pitch tables
 - creating, 124
 - list, 124
 - PitchBendMode, 30, 96
 - PitchTbl (global), 96
 - PitchTbl (sound), 30
 - PitchTbl (track), 14
 - Play/Top button, 58
 - Playing a sequence, 58
 - Playing the ASR-X Pro Demo, 4
 - PlayMode, 29
 - Polyphony, 6
 - Powering up ASR-X Pro, 2
 - when using SCSI, 85
 - ppqn, 59
 - Pre-quantization, 65
 - PressureMode, 17
 - Pre-Trigger, 52
 - PROC, 36
 - Prog, 12, 13, 27, 42
 - ProgramChngeRecv, 18
 - Protecting a SCSI disk, 100
 - PtchModSrc, 30
 - Punching in
 - manually, 58
 - with a foot switch, 94
- Q**
- Q, 32
 - Quantize To, 68
 - Quantize track?, 67
 - QuantizeNoteOffs, 72
 - Quantizing tracks
 - adding randomness, 71
 - adding swing, 70
 - as you record, 65
 - in a specific key range, 71
 - method
 - Normal or Delta, 69
 - moving the ends of notes, 72
 - overview, 67
 - setting the quantization value, 68
 - setting the strength, 70
 - setting which notes are quantized, 71
 - shifting the whole track, 71
 - templates
 - described, 68
 - list of templates, 115
 - saving your own, 72
 - to FLASH, 102
 - the lengths of notes, 72
- R**
- RAM kit
 - defined, 24
 - how it's named, 25
 - where it goes, 24
 - RAM pitch table, 124
 - RAM, defined, 5
 - Ramp Level (2), 31
 - Ramp Level (3), 31
 - Ramp Time (2), 31
 - Ramp Time (3), 31
 - RAM-SND, 8
 - Random, 71
 - Rate ModSrc, 34
 - Real-time modulation, 44
 - Rec Mode (sampling/resampling), 51
 - Record Mode, 61
 - Record Time, 51
 - Record/Scoop button, 58
 - Recording. *See* Sequencing
 - RecordQuantize, 65
 - Reduce sample bits?, 37
 - Region FromPoint, 65
 - Region ToPoint, 65
 - Regions
 - defined, 64
 - end
 - To=, 65
 - ToPoint, 65
 - start
 - From=, 65
 - FromPoint, 65
 - Registered Parameters. *See* RPNs
 - Release Time (5), 32
 - Removable drive. *See* SCSI
 - Rename disk files?, 100
 - Rename sequence?, 75
 - Rename Sound?, 35, 101
 - Renaming a sound, 101
 - Replace, 61

- Resampling. *See* Sampling/Resampling
 - Resampling Setup button, 50
 - Reset All Controllers
 - enabling reception, 97
 - reception behavior, 120
 - Reset SCSI bus?, 100
 - ResetControlRecv, 97
 - Resolution of sequencer, 59
 - Resonance (Q), 32
 - ResVCF→DDL. *See* User's Guide
 - Retro synth sounds. *See* Stomper
 - Rev→Chorus. *See* User's Guide
 - Rev→Flanger. *See* User's Guide
 - Rev→Phaser. *See* User's Guide
 - Reverb. *See* Global reverb
 - adding to pad sound, 27
 - adding to track sound, 13
 - Reverb Return Level, 44
 - Rewinding to the beginning of a sequence, 58
 - Roland S-770 sounds
 - loading, 91
 - translation, 91
 - Roll Breakpoint, 33
 - Roll Slope, 33
 - Rolloff Mode, 33
 - ROM Pitch Tables list, 124
 - ROM sounds list. *See* User's Guide
 - ROM waves list, 111
 - ROM, defined, 5
 - ROM-SND, 8
 - RotarySpeaker. *See* User's Guide
 - RPNs
 - defined, 122
 - using, 122
- S**
- Sample memory
 - as shipped from factory, 104
 - expansion options for the ASR-X Pro, 104
 - Sample Start, 29
 - Sample, defined, 49
 - Samples. *See* Waves
 - Sampling In Progress, 53
 - Sampling Level LEDs, 50
 - Sampling/Resampling
 - available sampling time, 104
 - building your own kit, 54
 - how sounds are named, 54
 - making a sample, 53
 - overview
 - Audio Inputs, 50
 - audio sources, 49
 - resampling, defined, 49
 - sampling, defined, 49
 - Scratch Pad, 49
 - wave, defined, 49
 - sending to pads
 - explained, 54–55
 - process, 53–54
 - setting up, 50–52
 - automatic normalization, 51
 - saving setup to FLASH, 102
 - selecting a source, 50
 - selecting an effect bus, 51
 - setting sampling time, 51
 - setting the pre-trigger time, 52
 - setting the trigger level, 52
 - setting the trigger mode, 52
 - stereo or mono?, 51
 - where sounds go, 54
 - Save button, 89
 - Save quantize as?, 72
 - Save these settings?, 102
 - Save to disk?, 89
 - Saving your own quantizing template, 72
 - sbx, 89
 - Scale loudness?, 36
 - Scale time?, 38
 - Scan SCSI devices?, 87
 - Scoop, 58
 - Scope, 73
 - Scratch Pad
 - described, 49
 - playing, 53
 - saving contents to disk, 90
 - when it's erased, 54
 - SCSI
 - advantages/disadvantages, 81
 - bus
 - explained, 82
 - not functioning, 99
 - terminating correctly, 84, 95
 - unscrambling, 99
 - using proper device IDs, 83, 95
 - cables
 - connecting, 85
 - device Ids
 - explained, 83
 - setting the ASR-X Pro's, 95
 - disk
 - selecting for use, 86
 - scanning SCSI bus, 87
 - disks
 - formatting, 98
 - folders
 - creating new
 - using ASR-X Pro, 88
 - using computer, 88
 - explained, 85
 - default, 85
 - invisible, 85
 - navigating, 87
 - powering up system, 85
 - preparing for, 85
 - termination
 - explained. *See* setting the ASR-X Pro's. *See*
 - troubleshooting, 86
 - utilities
 - disk copying, 98
 - disk formatting, 98
 - disk optimization, 99
 - re-setting SCSI bus, 99
 - write-Protection, 100
 - What is SCSI?, 82
 - SCSI Device ID, 95
 - SCSI II. *See* SCSI
 - SCSI Termination, 95
 - Select Device?, 87
 - Select Track buttons, 7
 - Selecting Sequences, 60
 - Semitone Shift, 14
 - SemitoneTuning, 30
 - Send to Pads button, 54
 - Sending to pads, 53–55
 - Seq parameter, 74
 - Sequence banks, 89, 91
 - Sequence Edit button, 60
 - Sequence length, 64
 - Sequence names, 75
 - Sequence Process button, 67
 - Sequence Select button, 59
 - Sequencing
 - chaining sequences, 76
 - changing time signatures, 64
 - creating a new sequence, 60
 - creating songs, 77–78
 - looping a sequence, 64
 - metronome click and countoff, 65–67
 - operating the transport controls, 58
 - overview, 57–58
 - playing part of a sequence, 65
 - processing
 - part of a track, 65
 - processing sequences
 - appending, 75
 - copying, 75
 - erasing all sequences, 76
 - erasing current sequence, 76
 - overview, 67
 - renaming, 75
 - processing tracks
 - copying, 72–74
 - erasing, 74
 - overview, 67
 - quantizing, 67–72
 - undoing, 67
 - quantizing as you record, 65
 - recording fade-outs, etc., 63
 - recording from MIDI, 79
 - undoing tracks, 79
 - recording modes, 61
 - recording tempo changes, 63
 - recording track parameter changes, 63
 - resolution, 59
 - selecting a sequence, 60
 - setting tempo
 - by tapping, 60
 - with parameter, 60
 - step recording, 61
 - using regions, 64
 - Sequencing overview
 - What's a sequence?, 58
 - What's a sequencer?, 57
 - Set system prefs?, 93
 - Shift, 71
 - Show free memory?, 101
 - Shrinking samples. *See* Scale time?
 - SIMM chips
 - installation procedure, 104–6
 - overview, 105
 - requirements, 105
 - Small Plate. *See* User's Guide
 - Small Room. *See* User's Guide
 - SMDI, 86
 - SMF, 89
 - SND, 91
 - solo, 19
 - Soloing a track
 - using Mute/Solo button, 19
 - Song mode, 77
 - creating a song, 77
 - editing a song, 77–78
 - exiting, 77
 - playing a song, 77
 - Song Position Pointer
 - transmission and reception, 97
 - sou, 89
 - Sound Name knob, 3
 - Sound Type knob, 3
 - SoundFinder, 8, 35
 - changing a sound's type; sound is assigned. Press the Yes button is response to, 102
 - list of sound types, 112
 - SoundFinder parameter, 102
 - Sounds
 - changing SoundFinder type, 102
 - USER-SND and DEMO-SND, 102
 - erasing all sounds, 101
 - erasing from a pad
 - shortcut, 25
 - erasing from a track
 - shortcut, 11
 - using the Memory Manager, 101
 - listing of ROM sounds. *See* User's Guide
 - renaming a sound, 101
 - selecting
 - for a pad, 25
 - for a track
 - via MIDI, 10
 - selecting for a track
 - from front panel, 8–9
 - structures
 - illustration, 22
 - kit sounds, defined, 22
 - standard sounds, defined, 22
 - types, 8
 - list, 112
 - Source, 50
 - spb, 89
 - Spinner→Rev. *See* User's Guide
 - ssx, 89
 - Standard MIDI File, 89
 - Standard sounds, 22
 - Start demo playback?, 4
 - Start/Loop, 29
 - Start/Stop button, 53

- StartToEndIndex, 29
- Static warning, 103
- Step recording, 61
 - chords, 63
 - overview, 61
- Step Size, 62
- Stereo
 - panning a pad sound, 26
 - panning a track sound, 13
- Stereo Chorus. *See* User's Guide
- Stomp!, 39
- Stomper, 39–40
- Stop/Locate button, 58
- Stopping a sequence, 58
- Storage device selection, 86
- Strength, 70
- Stretching samples. *See* Scale time?
- Sustain Level (4), 32
- Sustain Pedal, 35
- Sustain/SostRecv, 18
- SW-10 foot switch, 6
- SW-2 foot switch, 6
- SW-6 foot switch, 6
- Swing, 70
- SyEx Device ID, 97
- Synchronizing
 - effects, 97
 - LFOs and noise generators, 97
 - to external sequencer, 97
- SyncLFO&Noise, 15
- Synthesize sound?, 39
- Synthesize Stomper sound?, 39
- SysCTRL1-4 Recv, 18
- SysCtrls
 - setup, 97
- SyEx data on SMF tracks, 89
- System pitch bend, 95
- System pitch table, 96
- System/MIDI button, 92
- System/MIDI parameters
 - overview, 92
- SYSTEMSETUP, 89, 91
 - automatic loading of, 89
- T**
- Template, 68
- Templates list, 115
- Termination. *See* SCSI Termination
- Threshold, defined, 52
- Time, 62
- Time compression/stretching. *See* Scale time?
- Time Signature, 64
- Timing correction. *See* Quantizing tracks
- TK symbol, 7
- To= parameter, 65
- Touch Curve, 93
- Track Edit/Mix/FX Bus button, 11
- Track Mix mode, 63
- Track Pan, 13
- Track ParamReset, 95
- Track ParamReset Behavior, 121
- Track Sound button, 7
- Track Undo, 67
- Track Volume, 12
- TrackBreakpoint, 33
- TrackMIDIOut, 13
- Tracks
 - introduction, 7
 - parameters
 - editing, 11
 - resetting, 8
 - selecting, 7
- Tracks
 - and Track Param Reset, 121
 - and Track ParamReset, 95
 - parameters
 - recording changes, 63
 - resetting, 121
 - selecting sounds, 8–11
- Transfers via SMDI, 86
- Transport buttons, 58
- Trig Mode, 52
- Trigger, 52
- Truncate length?, 38
- Tunable Spkr. *See* User's Guide
- Tuning Shift, 27
- Tuning Tables
 - creating, 124
- Turning click on or off, 66
- Turning on ASR-X Pro, 2
- U**
- Undo track ?, 67
- USER TEMP, 72
- USER-SND, 102
 - quick selection, 9
- Using RPNs, NRPNs to Edit Parameters, 122
- V**
- Value knob, 3
- Value, defined, 3
- Vel Curve, 32
- Vel Levels ModAmt, 32
- VelAtckTimeModAmt, 32
- Velocity Mode, 17
- VelocityRange Hi, 17
- VelocityRange Lo, 17
- VelRelTimModAmt, 32
- Voice Mode, 30
- Vol ModSrc, 33
- Vol/MixPolarity, 13
- Volume, 2
 - of a pad, 26
 - of a track, 12
- Volume (click), 66
- Volume knob, 2
- Volume ModAmt, 33
- Volume(7) Recv, 18
- W**
- Waiting For Trigger., 53
- wav files, 91
- Wave expansion board
 - installation procedure, 106–8
 - name, 102
- Waves
 - copying, 38
 - defined, 49
 - inverting, 37
 - list of built-in, 111
 - normalizing
 - automatically, 51
 - manually, 36
 - playing a wave on all pads, 55
 - processing, 36–39
 - reducing sample bits, 37
 - scaling loudness, 36
 - time-scaling, 38
 - truncating, 38
- WetReverb, 13
- WetReverb FX Bus, 44
- What can be sampled?, 49
- What Is MIDI?, 115
- Where did my track settings go?, 8
- Why do I only hear a few drum sounds?, 23
- Why don't the pads do anything?, 96
- Why is my edit doing nothing?, 12
- Why won't my SCSI drive work?, 86
- Window Minimum and Maximum, 71
- World Wide Web, 1
- Wrench, 103
- Writable disks, explained, 82
- Write-Protect, 100
- X**
- X-8 output expander, 6
- X-Audio audio CDs, 6
- XMit MIDI Clocks, 97
- Y**
- Yes button, 3