

5864 6.




Tous les oscillogrammes se rapportant à la masse TEA 2164 G pin 1 etc. / Oscillogramm-Meßpunkt auf Masse an TEA 2164 G Pin 1 etc. bezogen

Toutes les mesures se rapportant à




RCN 620
RCN 621
RCF 630
RCF 631



CRT board
Connections
5858 20 50, ...




Oscilloscope
Wave forms at
Oscilloscope
Oscilloscope




3 switch-mode power supply are approx. 30% of those applying in normal operating mode (except for U5).
nungen am Schaltkreisausgang bei ca. 30% des Normalbetriebes (außer U5).
reces à la sortie du block secteur de commutation s'élèvent à 30% env. du fonctionnement normal (à part U5).
altezza dell'uscita del trasf. di rete le tensioni sono il 30% ca. delle tensioni nel funz. normale (eccetto U5).
ir matdellens spanninggar ca. 30% av normalt varde (forutom U5).

After DF02 has been replaced, the AGC must also be recalibrated.
Nach Austausch von DF02 muß auch die AGC neu abgeglichen werden.
Après avoir remplacé DF02, AGC doit également être rééquilibrée.
Dopo aver sostituito il DF02 è necessario equilibrare nuovamente anche l'AGC.
AGC in måste också justeras när DF02 byts

↓ 620	5652 19 10
↓ 621	5652 19 19
↓ 630	5652 19 23
↓ 631	5652 19 24




**AM-Ton ZF (Multi
AM sound IF
Son AM F.I.**



**T board/ Bildröhrenanschlußplatte/
nnexion tube image/ Collegamento cinescopio/ Bildrörsplatten**



↓ 20 50, ..51, ..54, ..55, ..57, ..58




→ NF → Ver
→ FBAS → Hor
Direction arrow/ Richtungspfeil →
Flèche de direction/ Freccia di direzione

Assembly group abbreviations/ Baugruppenkürzbezeichnungen
Codifica dei moduli/ Désignations abrégées des sous-ensembles
Blockförkortningar
D = Color decoder/ Decodificatore colore/ Färgdekoder
K = Hor. deflection/ Deflessione orizzontale/ Horizontal avlänkning
S = Vertical/ Verticale/ Vertikal
I = AF/ ZF/ LF
L = IF/ MF/ IF
F = Control unit/ Unità di comando/ Kontrollenhet
A = Sound/ Audio/ Ljud
O = Power supply/ Circuito aliment. rete/ Natdel
H = C.R.T. board/ Colleg. cinescopio/ Bildrörsplattan
R = Teletext/ Televideo/ Text-TV

Oscillogrammi bei Stand-by-Betrieb
Waveforms at stand-by mode
Oscillogrammes pour fonctionnement en stand-by
Oscillogrammi in modo -stand-by-




Oscillogrammi bei Normalbetrieb
Waveforms at normal operation
Oscillogrammes en mode de fonc. normal
Oscillogrammi in presenza di esercizio normale



TELETEXT decoder
VIDEOTEXT- Decoder
Decoder TELEVIDEO
5854 40 37

AM-Ton ZF (Multinorm sets)
AM sound IF
Son AM F.I.




→ NF → Ver
→ FBAS → Hor
Richtungspfeil →
on/ Freccia di direzione

Abbreviations/ Baugruppenkurzbezeichnungen
duli/ Designations abrégées des sous-ensembles
gar
oder/ Decodificatore colore/ Färgdekoder
ction/ Deflessione orizzontale/ Horizontal avlankning
verticale/ Vertikal

nit/ Unità di comando/ Kontrollenhet
udio/ Ljud
pply/ Circuito aliment. rete/ Nätdel
rd/ Collég. cinescopio/ Bildrörsplattan
Televideo/ Text-TV

el Stand-by-Betrieb
and-by mode
pour fonctionnement en stand-by
modo «stand-by»



TELETEXT decoder
VIDEOTEXT- Decoder
Decoder TELEVIDEO
5854 40 37

