


Monophone DS Number 5 Special Ringer



FOR GROUND RING, RINGER IS
DISCONNECTED FROM TERMINAL 5,
AND CONNECTED TO GROUND

