

Calling Card Set-Up Instructions

If you wish to use a calling card for long distance calls on your new cellular phone, you must first set up your calling card information. Your phone can save information from two calling cards.

Saving calling card information:

1. Press Menu 4 1 3.
2. Scroll to the desired calling card, then press Options.
3. Scroll to Edit, then press OK.
4. Enter your security code (see page 51), then press OK.
5. At Dialing sequence, press Select. Press down "V" to choose the dialing sequence your card uses, then press Select.

Dialing sequence	Use for cards that require you to:	Cards using this sequence
Access # + phone # + card #	Dial 1-800 access number, then phone number, then card number (+ PIN if required)	MCI, AT&T, True Choice, Sprint Canada, Unitel
Access # + card # + Phone #	Dial 1-800 access number, then card number (+ PIN if required), then phone number	NetworkMCI, WorldPhone, MCI
Prefix + phone # + card #	Dial the prefix (any numbers that must precede the phone number) and phone number you want to dial, then card number (+ PIN if required)	GTE, PacBell, AT&T, Stentor

Note: the order of the following steps may vary, depending on which dialing sequence your card uses. This procedure might not work well with all calling cards.

6. Enter access number (usually the 1-800 number listed on the back of the calling card) then press OK.
7. Enter your card number and/or PIN, then press OK. Your phone will display Save changes? Press OK.
8. Press down "V" to reach Card name, then press Select. Enter the card name using your phone's keypad, then press OK.

(Source: Nokia 5160 manual)