



* ADJUST L25/R205 FOR PROPER HORIZONTAL WIDTH

MIT L25/R205 HORIZONTAL-AMPLITUDE EINSTELLEN

REGLER L25/R205 POUR OBTENIR UNE CORRECTE AMPLITUDE HORIZONTALE

REGOLARE L25/R205 PER UNA CORRETTA AMPIEZZA ORIZZONTALE




(TZ)

110* ADJUST R203 FOR PROPER TRAPEZIUM

MIT R203 TRAPEZENTZERRUNG EINSTELLEN

REGLER R203 POUR AJUSTER LE TRAPEZE

REGOLARE R203 PER CORREGGERE IL TRAPEZIO



(TW)



110* ADJUST R200 FOR PROPER PIN-CUSHION

MIT R200 KISSEN EINSTELLEN


REGLER R200 POUR AJUSTER LE COUSSIN

REGOLARE R200 PER CORREGGERE IL CUSCINO

(AGC)



SYMBOLS			
CAPACITORS		RESISTORS	
MELF		MELF	
MYLARD		FUS	
<200V		1/4 W	
200V		1/2 W	
300V		1 W	
400V		2 W	
600V		5 W	
630V			
>650V			



AUTOMATIC GAIN CONTROL
 AUTOMATISCHE VERSTÄRKUNGSREGELUNG
 CONTRÔLE AUTOMATIQUE DU GAIN
 CONTROLLO AUTOMATICO DEL GUADAGNO

FOCUS
 BILIOSCHARFE
 FOCUS
 FUOCO

SCREEN GRID
 SCHIRMGITTERSPANNUNG
 TENSION DU GRILLE-ECRAN
 GRIGLIA SCHERMO

88.65.50.387.00 / OTT.96

