

## 511 Bathurst

Starting from Exhibition Loop to Bathurst Station;

- East out of Exhibition Loop via right of way to Fleet St.
- East on Fleet to Bathurst St. NA 375
- North on Bathurst to Bathurst Station

Return to Exhibition

- Exit Bathurst Station NA 273
- South on Bathurst to Fleet St. NA 374
- West on Fleet to Exhibition Right of way

First platform at west end of loop is used during major events for unloading. With the second platform being used for loading. At all other times loading and unloading are done on the second platform.

### BATHURST SHORT TURN:

**Fleet Loop** is a north (east) and southbound (west) short turn:

- East on Fleet to Lighthouse NA 314
- South into Fleet Loop to manual switch, Open switch to return to Exhibition Loop OR
- West on Fleet to Lighthouse NA 197
- South into Fleet Loop to manual switch, close switch to return east on Fleet.

**Wolseley Loop** is a northbound only short turn

- Off load patron at Queen, North on Bathurst to Wolseley NA 296
- East on Wolseley to Loop
- South on Bathurst as instructed.

**Note:** These short turns are the common ones, Supervisors may use other turns at times.

Operator's restrooms are located at:  
Exhibition Loop  
Wolseley Loop  
Bathurst Station

