

## 512 St. Clair

Starting from St. Clair Station to Gunn's Loop

- West on St. Clair to St. Clair West Station Portal
- Enter Station OBEY TRAFFIC SIGNAL to NA 309
- Proceed to 1<sup>st</sup> platform to unload patrons.
- Proceed to loading platform, westbound is first
- Continue around station to NA 308, proceed straight
- Exit station via west portal to St. Clair Ave.
- West on St. Clair to Gunn's Loop

Return to St. Clair Station

- South on Gunn's Rd. to St. Clair
- East on St. Clair to St. Clair West Station Portal
- Enter Station OBEY TRAFFIC SIGNAL to NA 306
- Proceed left into station unload at 1<sup>st</sup> platform
- Proceed to loading platform, eastbound id 2<sup>nd</sup> platform
- Continue around station to NA 308, proceed left
- Exit station via east portal to St. Clair Ave
- East on St. Clair to St. Clair Station

### ST. CLAIR SHORT TURNS

**St. Clair West Station** is an east and westbound short turn:

- Enter Station as normal, unload all Patrons at unloading platform.

- Proceed to NA 307, NA to proceed straight onto sparetrack
- Layover on spare track until your time.

**NOTE:** You can't loop around station, so you must load patrons on the spare track.  
**USE CAUTION WHEN DOING SO, WATCH FOR OTHER STREETCARS AND BUSES**

**Oakwood Loop** is an east and westbound short turn:

- From the west on St. Clair to NA 336 OR
- From the east on St. Clair to NA 220
- North on Robina to Loop
- West into Loop, Layover in Loop
- South on Oakwood to NA 337
- Proceed east or west as instructed

**Lansdowne Loop** is a westbound only short turn:

- West on St. Clair to Lansdowne NA 144
- South on Lansdowne to Loop entrance
- West into Loop, Layover for time

**Townsley Loop** is a westbound only short turn:

- West on St. Clair to Old Weston Rd. Manual switch (MUST BE RESET)
- North on Old Weston to Loop
- Layover in loop for time
- South on Old Weston to St. Clair, eastbound as directed.

